





APRAMO® MULTII™ BOOSTER SEAT





TRAVEL & FEEDING
BOOSTER SEAT
20KG MAX APPROX. 9-36M









IMPORTANT! ADULT ASSEMBLY REQUIRED!
PLEASE READ THESE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE!

COMPONENT LIST

- A** SHOULDER STRAP
- B** BELT
- C** COVER BUCKLE
- D** TINY STORAGE BAG
- E** COOLER BAG
- F** BOOSTER SEAT BACK
- G** SAFETY SEAT BELT
- H** REAR SECURING STRAP BUCKLE
- I** REAR SECURING STRAP
- J** MAIN INNER STORAGE COMPARTMENT
- K** BOTTOM STORAGE BAG
- L** SEAT BOTTOM STRAP
- M** PLASTIC STRUCTURE





INSTRUCTION

SETTING UP THE BOOSTER SEAT

- Put the booster seat on chair or stadium chair with cooler bag (E) facing forward. (fig. 1)
- Unclip seat bottom strap (L), slide it under chair seat and refasten buckle. Tighten the strap until there is no slack. (fig. 2)
- Unlock cover buckle (C) and lift booster seat back (F) up, until it fit tightly on the adult chair back. (fig. 3, 4)
- Put rear securing strap (I) behind adult chair, fix the rear securing strap buckle (H) then tighten strap until there is no slack. (fig. 5)
- Try pull the seat bottom strap (L) to test the security of the seat and straps.
- After firmly attached the Apramo Multii™ booster seat to the adult chair, unlock the safety seat belt (G). (fig. 6)
- Place child in the Apramo Multii™ Booster seat with legs positioned on either side of the safety belts. (fig. 7)
- Lock the safety seat belt buckle. Tighten strap for a secure and comfortable fit. (fig. 8)

CLEANING

Your Apramo® Multii™ Booster Seat can be wiped clean with a damp cloth.



W A R N I N G !

**THE COVER CAN NOT BE TAKEN OFF FROM THE PRODUCT.
CARELESSNESS CAUSES FIRE.
THE PRODUCT HAS BEEN TESTED ACCORDING TO THE
RELEVANT SAFETY STANDARDS.**





WARNING!

NEVER LEAVE YOUR CHILD UNATTENDED!

ALWAYS USE THE CHILD RESTRAINT AND CHAIR ATTACHMENT SYSTEMS!


ENSURE THE CHAIR ATTACHMENT SYSTEM IS CORRECTLY FITTED AND ADJUSTED BEFORE USE!

ALWAYS CHECK THE SECURITY AND STABILITY OF THE CHAIR BEFORE USE!

DO NOT USE IF ANY PART IS BROKEN OR MISSING!



1. Do not use in motorbike or vehicle. Prevent serious injury or death from sliding out, falls or tipping over.
2. Always secure child in the restraint until child is able to get in and out of the booster without help (about 2 1/2 years old).
3. Never leave child unattended.
4. Never allow a child to push away from table.
5. The plastic structure is intended to be used with the fabric cover. Never use the plastic structure separately.
6. Always check security of fitting to adult chair before each use. Secure all booster seat straps tightly to chair back and chair seat.
7. Always assemble and use under adults supervision.
8. Do not use on stools, swivel chairs or any chair where all safety straps can not be properly secured.
9. Never use on uneven surface.
10. When using this product as a dining booster seat, only attach to a chair with back rest which has a min height of 50cm and min width of 30cm and min seat size of 36cm wide and 37cm front to back.



APRAMO UK LTD

UNITS 46-48,
DRAYTON MANOR BUSINESS PARK,
COLESHILL ROAD, TAMWORTH,
B78 3TL

www.apramo.com

